

# McDonnell & Miller Gasket Selector Guide

For Boiler Safety and Liquid Level Controls



## **HEAD GASKET**

(92-68) Part #323300 For Products: 94 Series



(355-16) Part #333600

For Products: 3155



For Products: New Type Misc. Valve & Strainer Assemblies (101A, 47, 51, 53, 847, 851, 551-S)



**HEAD GASKET** Part #318826 69 Series

**VALVE BRACKET GASKET** (37-27)Part #312800

For Products: Nos. 47, 247, 51, 51-S 53, 3155, 551-S, 847, 851, 851-S



**VALVE BRACKET GASKET** 

(21-27) Part #311100 For Products: 21, 25A, 27W



## **HEAD GASKET**

(F-26) Part #304100 For Products: 51, 51-S, 551-S, 53, 25A, 221, 3155



### GASKET

(37-39) Part #313200 Blow-Off Valve 14B, 47, 67, 70B



(67-12) Part #318800 For Products: Nos. 61, 64, 67, 69, 70, 70B, 767



## **BODY GASKET**

(37-26) Part #312700 For Products: Nos. 47, 247



## VALVE BODY **GASKET**

(21-12)Part #310800 21 Series



## **BELLOWS**

**BASE GASKET** (CO-11) Part #302500 For Products: Nos. 63



## VALVE GASKET

(37-28) Part #312900 For Products: 21 and 25 Series Nos. 3155, 515, 53



## FLAT FLANGE GASKET

(150-14) Part #325400 For Products: 150 Series





## RAISED FLANGE GASKET

(150-14H) Part #325500 For Products: 150 and 93 Series



## **BELLOWS BASE GASKET**

Part #318827 69 Series



## **HEAD GASKET**

(CO-12) Part #302600 For Products: Nos.42, 61,63, 64, 65



For Products: 3155